



57 Kremzow Road
Brendale Qld 4500

ENGINE RECONDITIONING

ABN: 58 010 969 472

RUN IN PROCEDURE

Run with JOE GIBBS BR30 or BR40 Break-In oil ONLY on dyno until rings are bedded in.
Dump oil, cut oil filter and check.

Run a mineral oil for first 1000km then service and use recommended weighted oil (refer to engine build sheet for bearing clearances and Joe Gibbs oil recommendations – sheet attached)

PHONE	FACEBOOK	WEB	EMAIL
3881 1342	PLR Performance Engines	www.plr.com.au	plrengines@outlook.com